



2007- 2014 TAHOE 3.5" CATBACK INSTALLATION INSTRUCTIONS

1. Disconnect battery
2. Remove the (2) 15 mm nuts holding exhaust to "Y" Pipe.
3. Remove exhaust from rubber hangers and remove exhaust. (It may be necessary to cut pipe in front of rear end for easier removal).
4. Lightly tap factory bolts from original "Y" pipe.
5. Install donut gasket to muffler inlet pipe and install on "Y" using supplied 2-1/2 stainless bolts and nuts. Lightly snug bolts.
6. Install muffler hanger with 2 rods into rubber hangers at front of rear axle with longer rod going to right side rubber.
7. Pull hanger toward rear of vehicle.
8. Place a 3-1/2 band clamp on to muffler inlet pipe and slip muffler on to pipe, Push hanger into position.
9. Install other hanger on to tail and slip over axle and onto muffler. Slide rear hanger into rubber.
10. Install tip and clamp on to rear of tail. Check clearance and tighten all clamps.
11. Reconnect Battery.